

## **2015 and Later Road Glide Speaker Installation**

Remove speaker grilles and stock speakers. Position a T16 speaker in each side with tweeter position back and in. Use two screws to lightly lock into place.



Using scribe tool, scribe speaker mounting frame around grille mount tab.





Then cut this area from frame.



This allows for grille tab to engage mount tab on fairing. Clean up edges with a file. Speakers are ready for install. Connect stock speaker terminal connectors to Rockford speaker. At this connection the wires are reverse polarity. You will correct this at the 2-pin connector into the speaker box.