

**Paul Yaffe's  
Bagger  
Nation™**



**14 & LATER  
FENDER ADAPTER  
INSTALL  
INSTRUCTIONS**



**PAUL YAFFE ORIGINALS**  
DESIGN & DEVELOPMENT

Thank you for purchasing Paul Yaffe's Bagger Nation products. Please read through these installation tips completely before installing your 14 & Later Fender Adapter.



1.  
Adapter Blocks &  
Included Hardware

1. The Bagger Nation 2014 & Later Fender Adapter blocks have a pair of holes on 3" centers & another on 3.25" centers. Locate each. (Fig 2 & 3)



2.



3.

2. The 3" center holes attach to the fender using the (4) 5/16 x 1/2 hex bolts, (4) 5/16 flatwashers & lock washers provided. The fender mount block side holes should point down when installed correctly. (Fig 4 & 5).  
Install both blocks at this time. Finger tight only.



3. Install fender between forks. Using the (4) 1 3/4 allen bolts. (4) 5/16 flat washers and (4) 5/16 lockwashers provided. Install front fender. (Fig. 6 & 7). Don't fully tighten bolts yet.



4. With mount blocks & fork bolts only snug you now have the opportunity to adjust your fender position to your liking.

You can pivot the fender to sit closer to tire up front if you like that look. Long fenders like the thicky need to be centered over the tire in the rear at tip before tightening.



8.

5. We use a couple of the left over nuts from your stock fender hardware to accomplish this. (Fig 8, 9, 9a)  
Once fender is adjusted to your liking you can tighten all fasteners at this time.



9.



9a.

**Thanks for choosing Bagger Nation Designs!  
Now go show off your new fender!**

A handwritten signature in black ink, appearing to read "Bagger Nation Designs".



**Paul Yaffe's**  
**Bagger**  
**Nation™**

602.840.4205  
BAGGERNATION.COM