

**Stealth 2 Installation**



Using template, mark holes.



Drill pilot holes, then drill holes using a 7/32" bit.



Flatten spots around holes on the underside of the fender to help the nuts sit flat.



Mount frame.  
**CAUTION:** Do not torque set screws into frame. Lightly seat only.



Tie wires into taillight & ground circuits.

