



## Bagger Nation Custom Wedgy Brake Pedal

Thank you for choosing Paul Yaffe Originals and Bagger Nation! Follow these simple instructions and installing your new Custom brake pedal will be a breeze!

1. Remove the existing rubber pedal. **(See Fig 1)**
2. Mark your brake pedal with a marker and a straightedge. **(See Fig 2)**
3. Cut your brake pedal with a cutoff wheel. **(See Fig 3 and Fig 4)**
4. Test fit your new Wedgy brake pedal on the brake arm. After fitment is verified paint the cut edge of the arm. **(See Fig 5)**
5. Apply red Loctite and attach the brake pedal with supplied screw and washer. **(See Fig 6)**



**Fig 1**



**Fig 2**



**Fig 3**



**Fig 4**



**Fig 5**



**Fig 6**